

# MC331 POWERPOINT REMOTE CONTROL

## INSTALLATION

The USB transmitter/receiver for the Powerpoint remote control is located on the bottom of the device. This USB device should be removed and inserted into any USB port on the computer. No software is required to operate the remote control.

Please ensure the USB device is returned to the remote control when finished, to avoid loss.

## OPERATION

There are seven control buttons located on the Powerpoint remote mouse. Six are located on the front, and one on the back of the control. The function of the various buttons are as listed below...

- White square button: Blanks/Restores Powerpoint slide display.
- Left/Right arrow buttons: Moves backward/forward through Powerpoint slides.
- Large round toggle button: Controls computer's mouse cursor.
- Small round button: Mouse right-click.
- Button on back of control: Mouse left-click, or skip to next slide in Powerpoint.
- Red Star button: Laser pointer.

**DANGER:** Do not look into the laser pointer emitter, or point the beam at other people.

**NOTE:** The Powerpoint remote control requires a CR2025 battery. If the control does not operate (eg. the laser pointer does not function), please contact the main office (MC134) for a replacement battery.